



USB-2084 USB I/O Module with 4-ch/8-ch Counter/Frequency/

Features

- 8-ch for Frequency and Up Counters Types
- 4-ch for Up/Down, Dir/Pulse and A/B Phase Counters Types
- Support digital filter (1~32767 us)
- No external power supply (USB Bus Powered)
- Plug-and-Play without driver installation
- Lockable USB cable
- Module supported for Win2000/XP , Win7/8/10/11 (32/64 bit) and Linux (32/64 bit)

Encoder Input

CE LA FC Cons X

Introduction

The USB-2084 is a full-speed USB device with 8-ch for Frequency and Up Counters, or 4-ch for Up/Down, Dir/Pulse and A/B Phase Counters, and offers features for industrial control and manufacturing test applications, such as factory automation or embedded machine control. With the true Plug & Play capability, it needs not opening up your computer chassis to install boards-just plug in the module, then get or set the data. Owing to another USB feature known as "hot-swapping", users do not even need to shut down and restart the system to attach or remove a peripheral.

The USB I/O utility can help users to configure and test USB-2084 quickly and easily without programming; In addition, we also provide the friendly API library and demos for users to develop own USB application with various application development tools (VB/C++/C#.NET/ VB.NET/LabVIEW). Therefore, the USB-2084 is the perfect way to add measurement and control capability to any USB capable computer.

Software

USB I/O Utility

USB I/O Utility provides a simple way to easily test and instant acquire data for all ICP DAS USB I/O series modules without programming.

- Automatically scan all ICP DAS USB I/O modules
- Easily and quickly configure and test USB I/O modules
- Completely and precisely log I/O data for analysis



VB/C++/C#.NET/VB.NET/LabVIEW SDK

ICP DAS provides a SDK for USB I/O modules to help user to develop own project easily and quickly. The SDK can be supported in VB/C++/C#.NET/VB.NET/LabVIEW to fulfill project development.



Applications

- Counter measurement
- Frequency measurement
- Motion control

System Specifications

USB					
Specification	USB 2.0 Full-Speed (12Mbps)				
CPU Module					
Watchdog Timer	1 Hardware watchdog (1.6 second) 1 Software watchdog (Programmable)				
EMS Protection					
ESD (IEC 61000-4-2)	4 kV contact for each terminal 8 kV air for random point				
LED Indicators					
Status	3 x Power and Communication				
	8 x Counter Input				
Power					
Consumption	1.3 W (Max.)				
Mechanical					
Dimensions (mm)	33 x 107 x 102 (W x L x H)				
Environmental					
Operating Temperature	-25 ~ +75 °C				
Storage Temperature	-40 ~ +85 °C				
Humidity	10 ~ 95% RH, Non-condensing				

I/O Specifications

Counter/Frequency/Encoder Input			
Channels	4 channels for Up/Down, Dir/Pulse and A/B Phase types 8 channels for Up and Frequency types		
Туре	Up, Frequency, Up/Down, Dir/Pulse, A/B Phase		
TTL, ON Voltage Level	+2 VDC ~ +5 VDC		
TTL, OFF Voltage Level	0 VDC ~ +0.8 VDC		
Frequency Accuracy	±0.4%		
Digital Filter	1 ~ 32767 uS (Software programmable)		
Individual Channel Configuration	Yes		
Intra-module Isolation	3000 V _{DC}		
Isolated, Frequency	250 KHz Max.		
Non-isolated, Frequency	500 KHz Max.		
Isolated, Input Level	ON Voltage Level: +4.5 VDC \sim +30 VDC OFF Voltage Level: +1 VDC Max.		
Contact Rating	0.25 A @ 250 V _{AC} 0.24 A @ 220 V _{AC}		

Pin Assignments

		Terminal No.		Pin Assignment	
1		PWR 🗖		01	C0A+
	8	RUN 🗖		02	C0A-
	ERR 🗖	[= (03	C0B+	
	8		[04	C0B-
	8		Ç II	05	C1A+
	Ŏ		ζ¤(06	C1A-
			07	C1B+	
			08	C1B-	
		(P (09	C2A+	
			ζ <u></u> = (10	C2A-
			(= (11	C2B+
	Q		[,∎(12	C2B-
	ICEDAS	(1	13	C3A+	
		[= (14	C3A-	
		(n (15	C3B+	
20	20 03D-20	U3D-2004	L -	16	C3B-
	,	[_ = (17	GND	
				18	GND
				19	N/A
			Ŀ	20	N/A

Dimensions (Units: mm)



Wire Connections

Input Mode	Isolated	Non-isolated
Dir/Pulse	Vin+ (Pulse) - Vin- (Pulse) - Vin+ (Dir) - Vin+ (Dir) - Vin- (Dir) - CXA+ CXA- CXB+ CXB- CXB-	Vin+ (Pulse) - CXA+ Vin+ (Dir) - CXB+ Vin- (Pulse) and - CXB+ Vin- (Dir)
Up/Down	Vin+ (Up) - □ ← CxA+ Vin- (Up) - □ ← CxA- Vin+ (Down) - □ ← CxB+ Vin- (Down) - □ ← CxB+	Vin+ (Up) - □⊖ CxA+ Vin+ (Down) - □⊖ CxB+ Vin- (Up) and - □⊖ GND Vin- (Down)
Up	Vin+ (Up0) - Vin- (Up0) - Vin- (Up1) - Vin+ (Up1) - Vin- (Vin+ (Up0) - CXA+ Vin+ (Up1) - CXA+ Vin- (Up0) and - CXB+ Vin- (Up1) - CXB+ GND
A/B Phase (Quadrant)	Vin+ (A0) - □⊖ CxA+ Vin- (A0) - □⊖ CxA- Vin+ (B0) - □⊖ CxB+ Vin- (B0) - □⊖ CxB+	Vin+ (A0) - □ Vin+ (B0) - □ Vin+ (B0) - □ Vin- (A0) and - □ Vin- (B0)
Frequency	Vin+ (Freq0) - □⊖ CxA+ Vin- (Freq0) - □⊖ CxA+ Vin+ (Freq1) - □⊖ CxA- Vin+ (Freq1) - □⊖ CxB+ Vin- (Freq1) - □⊖ CxB-	Vin- (Freq0) - Vin- (Freq1) - Vin- (Freq0) and - Vin- (Freq1) - Vi

Ordering Information

	USB I/O Module with 4-ch/8-ch Counter/
USB-2084 CR	Frequency/Encoder Input (RoHS)
	Includes 1.5M USB Cable (CA-USB15)